




## FEATURES OF YOUR SIMPLE PRESS™ IRON

1. SPRAY MIST® Release
2. Covered Water Fill Hole
3. Fabric Select Dial
4. Steam Lever
5. SPRAY MIST® Button
6. SHOT OF STEAM® Button / Vertical Steam (*select models only*)
7. MOTION SMART® Auto-Off Indicator
8. 360° Tangle-Free Swivel Cord
9. Self-Clean Button
10. See-Through Water Reservoir
11. Soleplate
12. Storage Strip™ Indicator
13. Anti-Calcium System (*select models only*)



## CARACTÉRISTIQUES DU FER SIMPLE PRESS™

1. Orifice d'atomisation SPRAY MIST®
2. Orifice de remplissage à volet
3. Cadran de sélection des textiles
4. Levier de vapeur
5. Bouton d'atomisation SPRAY MIST®
6. Bouton du jet de vapeur SHOT OF STEAM® / Vapeur verticale (*certaines modèles seul*)
7. Témoin marche-arrêt MOTION SMART®
8. Cordon articulé 360° non emmêlant
9. Bouton d'autonettoyage
10. Réservoir translucide
11. Semelle
12. Indicateur Storage Strip™
13. Système anti-tartre (*certaines modèles seul*)

## IRONING TIPS

- Always read garment labels and follow the manufacturer's ironing instructions.
- Sort the articles to be ironed according to the type of fabric.
- You should first iron garments requiring low temperature (*e.g., silks and synthetics*) to avoid damaging them with an iron that is too hot.
- If you are unsure of the fabric content of the garment, test a small area, such as a seam or facing, before ironing a visible area. Start with a low temperature and gradually increase the heat to find the best setting.
- When changing the temperature from a high setting to a low setting, allow approximately 5 minutes for the lower temperature to be reached.
- When steam ironing, use long, slow passes over the fabric. This will allow the steam to penetrate the fabric while allowing the heat of the soleplate to dry out the moisture.
- To iron linens, turn garment inside out. Be careful not to use an iron that is too hot because the lining may melt or stick to the soleplate.
- To iron zippers, use an ironing cloth or make sure the zipper is closed and iron over the flap. Never iron directly over an unprotected zipper.
- Use the Ironing Guide to select the best setting and method for the fabric you plan to iron.
- SUNBEAM® irons are designed to be used with ordinary tap water. In areas where hard water exists, Sunbeam recommends running one to two iron water tanks full of distilled water every month. Using distilled water on a monthly basis will help to prevent mineral build up. **CAUTION:** Do not overuse distilled water. It may cause the iron to drip or spit if it is used too often.

## CONSEILS PRATIQUES

- Lisez toujours les instructions de repassage que fournit le fabricant et observez-les.
- Triez le linge à repasser selon la nature des textiles.
- Repassez en premier les pièces nécessitant la température la plus basse (*synthétiques et soie, par exemple*) pour ne pas les abîmer avec un fer qui serait trop chaud.
- Si vous ne connaissez pas la nature du tissu, faites tout d'abord un essai sur une couture ou une parmenture. Commencez le repassage à une température basse que vous augmenterez progressivement jusqu'à la température idéale.
- Laissez refroidir le fer environ 5 minutes lorsque vous devez passer d'une certaine température à une température inférieure.
- Repassez à la vapeur en donnant de longs coups de fer lents. La vapeur aura ainsi le temps de pénétrer dans le tissu et la chaleur de la semelle, de la sécher.
- Dans le cas de lin, repassez le vêtement sur l'envers et n'utilisez pas un fer trop chaud car la doublure pourrait fondre ou coller à la semelle.
- Utilisez une pattemouille pour repasser les glissières ou assurez-vous qu'elles soient fermées et repassez leur rabat. Ne passez jamais directement le fer sur les glissières.
- Consultez le guide de repassage pour choisir le réglage approprié et la meilleure façon de repasser les divers textiles.
- Les fers à repasser SUNBEAM® sont conçus pour utiliser l'eau du robinet. En présence d'eau dure (calcaire), Sunbeam conseille de repasser une ou deux fois par mois en remplissant le réservoir du fer d'eau distillée. Cet emploi mensuel d'eau distillée évitera l'entartrage. **ATTENTION:** N'utilisez pas de l'eau distillée trop fréquemment car le fer risquerait de dégouter ou de cracher.

## TO FILL THE WATER RESERVOIR

1. Make sure the iron is unplugged. Set the Steam Lever to /Off (Dry) and the Fabric Select Dial to OFF.
2. Lift the Water Fill Hole Cover.
3. Fill water cup with water. Pour water into iron water reservoir. Do not fill water reservoir beyond maximum fill level.

**WARNING:** To prevent the risk of burns, be careful when filling a hot iron with water. Hot metal parts, hot water and steam can cause injuries.

## DRY IRONING

1. Make sure the Steam Lever is turned to the /Off (Dry) setting.
2. Plug the cord into a 120-Volt AC outlet.
3. Turn the Fabric Select Dial to the fabric setting you desire. Allow the iron to heat for 2 minutes. While the iron is heating, make sure it is sitting on its heel rest on a stable, protected surface.

**NOTE:** While the Steam Lever is turned to the /Off (Dry) setting, you may still use the SHOT OF STEAM® or SPRAY MIST® features as long as the Fabric Select Dial is set to wool, cotton or linen. Please make sure the water reservoir is 1/4 full of water.

**TIP:** Refer to the Ironing Guide for the recommended setting for your fabric.

## STEAM IRONING

1. Follow the instructions for "Filling the Water Reservoir".
2. Plug the cord into a 120-Volt AC outlet.

3. Turn the Fabric Select Dial to the fabric setting you desire. Allow the iron to heat for 2 minutes. While the iron is heating, make sure it is sitting on its heel rest on a stable, protected surface.
4. Allow the iron to heat for 2 minutes, and then turn the Steam lever to the appropriate setting.

**TIP:** Refer to the Ironing Guide for the recommended setting for your fabric.

**IMPORTANT:** When not ironing, always set the Steam Lever to /Off (Dry) and the Fabric Select Dial to OFF.

## USING THE IRON'S SPECIAL FEATURES

### SPRAY MIST® FEATURE

The SPRAY MIST® feature is a powerful water spray mist that dampens the fabric to aid in removing wrinkles from heavy fabrics and for setting creases.

### To use the SPRAY MIST® Feature:

Press the SPRAY MIST® button firmly.

### SHOT OF STEAM® FEATURE

#### To use the SHOT OF STEAM® Feature:

Place the iron on top of the wrinkle and press the SHOT OF STEAM® button each time you would like an extra burst of steam. The SHOT OF STEAM® feature may be used continuously in approximately 3 second intervals.

#### VERTICAL STEAM (*select models only*)

The vertical steam feature allows your iron to function as a garment steamer.

**TIP:** When using the vertical steam on clothing, hang the clothing on a clothes hanger for best results. Hanging curtains and drapes may also be steamed.

#### To use Vertical Steam:

1. Make sure that the iron has heated up (2 minutes).
2. Hold the iron in a vertical position, with the iron close to but not touching the fabric you want to steam.
3. With your other hand, pull the fabric tight.

4. Press the SHOT OF STEAM® button for approximately 3-second intervals as you move the iron across the wrinkled area.

**WARNING:** To prevent the risk of burns, keep your hand away from the area being steamed.

**WARNING:** DO NOT steam garments while wearing them; this may result in injuries.

### CLEANING THE ANTI-CALCIUM SYSTEM (*select models only*)

The Simple Press™ iron houses an anti-calcium filter in the reservoir, which eliminates impurities from the water.

To prolong the efficiency of this filter:

1. Unplug the iron and allow it to cool.
2. Locate the water cup that accompanied the iron. Fill it with water to the Sunbeam logo in the top right corner. Add 1 teaspoon of salt to the water and fill the water reservoir with this solution.

3. Leave the solution in the water reservoir for 15 minutes, shaking occasionally, and then empty it.

4. Fill the water reservoir a second time with the salt water solution, shaking occasionally, and empty it again after 15 minutes.

5. Fill the tank with fresh water to rinse and empty.

The Anti-Calcium System should be cleaned approximately once a month.

### MOTION SMART® AUTO-OFF FEATURE

When the iron is plugged in, the Power Indicator will light steadily, indicating that there is power to the iron.

If you leave the iron:

- in a horizontal position without moving it, or accidentally tip the iron over, it will automatically stop heating after 30 seconds. The Power Indicator will blink to let you know that the iron has stopped heating.

in a vertical position (*on its heel rest*) without moving it, the iron will automatically turn off after 15 minutes. The Power Indicator will blink to let you know that the iron has stopped heating.

The Power Indicator will continue to blink until the iron is unplugged or reset.

To reset the iron:

- Move the iron back and forth and allow it to reheat for 2 minutes. The indicator will stop blinking and the iron will start heating again.

**WARNING:** THE MOTION SMART® Auto-Off is a safety feature, not a recommended means for turning your iron off. See "Caring for Your Iron After Use" for information on turning off your iron and storing it safely between use.

### STORAGE STRIP™ INDICATOR

The STORAGE STRIP™ indicator is an easy way to see when the iron is cool enough to store.

**To use the Storage Strip™ indicator:**

Turn iron on. In approximately 2 minutes, the STORAGE STRIP™ indicator will turn from black to red, indicating that the iron is too hot to store. When the iron is turned off, it will take the iron approximately 30 - 40 minutes for the STORAGE STRIP™ indicator to turn from red to black, indicating that the iron is cool enough to store.

**CAUTION:** The STORAGE STRIP™ indicator should only be used as a guideline. The iron should always be handled and stored with care.

## CARING FOR YOUR IRON AFTER USE

### TURNING OFF YOUR IRON

1. Turn the Steam Lever to /Off (Dry) and Fabric Select Dial to Off.

2. Unplug the iron from the power source.

**WARNING:** NEVER yank the power cord when unplugging the iron. This can damage the cord.

### STORING YOUR IRON

1. Allow the iron to cool.

2. If you do not use your iron on a daily basis, empty the water reservoir after each use for a longer iron life. To do so, unplug the iron, turn the iron upside down, open the fill hole cover, and allow water to flow from the fill hole. Shake the iron gently to remove trapped water drops.
3. Loosely loop the power cord around the heel rest and store the iron on its heel rest.

**IMPORTANT:** Wrapping the cord around the iron too tightly can damage the cord.

**TIP:** When not ironing, always set the Steam Lever to /Off (Dry) and the Fabric Select Dial to Off.

## MAINTAINING YOUR SIMPLE PRESS™ IRON

### CLEANING THE SOLEPLATE

Clean the soleplate if starch or other residue accumulate.

**To clean the Soleplate:**

1. Allow the iron to cool and then wipe it with a soft, damp cloth.

**WARNING:** DO NOT use abrasive cleansers, scouring pads or vinegar to clean the soleplate. This will damage the finish.

2. Run the iron over an all-cotton cloth to remove any residue.

### USING THE SELF-CLEANING FEATURE

You should use the Self-Cleaning feature once a month to maintain the optimal performance of your iron.

**To use the Self-Cleaning feature:**

1. Move the Steam Lever back and forth from /Off (Dry) several times to remove debris and minerals from the Steam Valve. This keeps water flowing into the steam chamber.

2. Fill the water reservoir with tap water to the MAX line.

3. Set the Fabric Select Slide to LINEN.

4. Plug the iron into a power outlet and allow the iron to heat for 2 minutes.

5. Turn the Fabric Select Slide to MIN and unplug the iron.

6. Hold the iron over a sink in a horizontal position.

**WARNING:** Be careful not to touch the iron's hot surfaces.

7. Press the self-clean button and hold. Water will begin dripping from the steam vents. To make sure that all of the water is removed from the tank, slowly iron side to side and front to back for 30 seconds. When rocking the iron, dip the nose of the iron slightly below the rear of the iron to make certain the water circulates completely. Release self-clean button after one minute.

8. Turn the iron upside down and allow the remaining water to flow out of the fill hole.

9. Dry the soleplate with a towel.

10. Plug in the iron and set the Fabric Select Slide to Linen. Let the iron heat for 2 minutes to dry out the iron completely.

11. Set the Fabric Select Slide to MIN, unplug the iron and allow it to cool.

### MOTION SMART® AUTO-OFF FEATURE

When the iron is plugged in, the Power Indicator will light steadily, indicating that there is power to the iron.

If you leave the iron:

- in a horizontal position without moving it, or accidentally tip the iron over, it will automatically stop heating after 30 seconds. The Power Indicator will blink to let you know that the iron has stopped heating.

## REMPLEISSAGE DU RÉSERVOIR

1. Assurez-vous que le fer soit débranché. Réglez le levier de vapeur à « /Off » (repassage à sec) et le cadran de sélection des textiles à « OFF ».

2. Levez le volet de l'orifice de remplissage.

3. Remplissez le godet d'eau puis versez l'eau dans le réservoir du fer. Ne remplissez pas le réservoir au-delà du repère MAX de remplissage.

**AVERTISSEMENT:** Remplissez très prudemment le réservoir d'un fer chaud. Les pièces en métal chaudes, l'eau chaude et la vapeur peuvent causer des brûlures.

### REPASSAGE À SEC

1. Assurez-vous que le levier de vapeur soit au réglage « /Off » (repassage à sec).

2. Branchez le cordon d'alimentation sur courant alternatif de 120 volts.

3. Réglez le cadran de sélection des textiles au tissu voulu. Laissez chauffer le fer pendant 2